KICKER by **Konami**

SOLDER SIDE		PARTS SIDE	
A	(EMPTY)	1	+12V DC
B	SPEAKER OUT	2	SPEAKER OUT
C	*2P KICK	3	2P JUMP*
D	*2P LEFT	4	2P RIGHT*
E	1P START	5	2P START
F	1P JUMP	6	2P UP*
H	1P KICK	7	SERVICE SW
J	1P RIGHT	8	1P LEFT
K	1P UP	9	2P DOWN*
L	COIN 1	10	COIN 2
M	1P DOWN	11	COIN COUNTER 1
N	(NOT USED)	12	COIN COUNTER 2
P	VIDEO GREEN	13	VIDEO BLUE
R	VIDEO RED	14	VIDEO SYNC
S	(EMPTY)	15	(NOT USED)
T	GND	16	GND
U	GND	17	GND
V	+5V DC	18	+5V DC

*COCKTAIL TABLE OR DUAL CONTROL UPRIGHT ONLY